



NOTES:

- 5 A.N.S.I. 161 2 1/8 HOLE IS NOT REQUIRED FOR RIM ONLY. SEE THE S1250 PULL TRIM TEMPLATE FOR EXIT DEVICE IS TO BE MOUNTED WITH PULL TRIM.
- 4 SURFACE OF DOOR WHERE EXIT DEVICE IS TO BE APPLIED MUST BE FLUSH.
- 3 SEE THE STRIKE TEMPLATE FOR MOUNTING LOCATION OF STRIKE.
- 2 ALL HOLES TO BE TAPPED SHOULD BE DRILLED AND TAPPED IN FIELD.
- 1 TOLERANCE ON ALL DIMENSIONS ± 1/32".

ARROW™

ASSA ABLOY

S1250 RIM EXIT DEVICE RIM ONLY OR LEVER

REV	DATE
A	08 / 16

S1250RIMLEVER

